FIXED TYPEE

EN — USER MANUAL

Thank you for purchasing the wireless keyboard.

CONTENTS OF PACKAGE:
1x user manual
1x wireless keyboard
1x USB-C cable

We recommend charging the keyboard to full capacity before first use. When charging with a cable, simply connect the included or other USB-C cable to the charger.

HOW TO ATTACH THE KEYBOARD TO YOUR IPAD:
1. Place the keyboard on a flat surface so that the hinge is away from you and the FIXED logo is on top.
2. Open the lid. The top of the lid will swing away from you.
3. Continue tilting until the lid is set at an angle you are comfortable with or until it snaps into place.
4. Place the iPad on the keyboard. The rear cameras should be on the top left to fit into the cutout in the keyboard.

OPENING THE KEYBOARD WITH THE IPAD INSIDE:
1. Place the keyboard on a flat surface so that the hinge is away from you and the FIXED logo is on top.
2. Open the lid until you adjust it to the angle you are comfortable with or until it snaps into place.

ADJUSTING THE ANGLE OF VIEW:
You can tilt your iPad forward and backwards for a comfortable viewing experience. The viewing angle range is from 60-125 degrees.

HOW TO PAIR AND CONNECT/DISCONNECT THE KEYBOARD:
1. Turn on the keyboard by sliding the power button on the side near the USB-C connector. The display will light up when you slide it.
2. Press the fn key and the B key together. The wireless device connection indicator will flash on the keyboard display to indicate that you have entered pairing mode.

fn + B

3. Turn on the Bluetooth function on your Apple iPad, then search for FIXED Typee and click pair.
4. Once the keyboard is successfully connected to your device, you can find it in the list of connected Bluetooth devices.

Once the keyboard has been successfully paired with the device, it is ready for use.
Once correctly paired, the keyboard will automatically connect to a known device the next time it is used.

TRACKPAD SETTINGS:
You can set the trackpad in Settings> General> Trackpad. You can adjust the speed at which the pointer scrolls across the screen, as well as the direction the screen scrolls when you swipe your fingers across it. You can also enable or disable the Tap Click and Secondary Two Finger Click features.

KEYBOARD SETTINGS:
- If you need to set the language, change the keyboard type, etc., go to Settings> General> Keyboard> Hardware Keyboard. Select „ISO" as the default keyboard type.
- The keyboard will automatically go into sleep mode if it is not used within 10 minutes. To wake up the keyboard, just press any key or click on the trackpad.

ADDED KEY COMBINATION FUNCTIONS:

	fn + ☼	Press these keys to switch between the intensity of the backlighting on the keys.
Pairing mode	fn + B	Press these keys to put the keyboard into pairing mode.
iPad brightness	fn + 1,2	Press ☼ or ☼ to decrease or increase the screen brightness.
Mission Control	fn + 3	Press ⌘ view a list of apps running on iPad.
Searching in Spotlight	fn + 4	To search for something on iPad, open Spotlight by pressing.
Dictation/Siri	fn + 5	To turn on dictation, press 🎤. You can dictate wherever you can enter text (for example, in Messages, Mail, Pages and other apps). Hold to 🎤 activate Siri, and you can speak your request right away.
Lock	fn + 6	Press 🔒 to lock the iPad.
Media	fn + 7, 8, 9	Use a key ◁◁ to move towards the beginning of a song, movie or presentation, a key ▷|| to start or pause playback, and a key ▷▷ to scroll to the end.
Turn off the sound	fn + 0	Press ◁ turn off the sound coming from the built-in speakers or sent to a wirelessly connected device.
Volume	fn + %, V	Press ◁) or ◁)) turn down or turn up the sound that comes from the built-in speakers or is sent to a wirelessly connected device.

CHARGING:
Plug the included USB-C cable into the keyboard and the other side into your iPad, charger or powerbank - charging starts automatically and the display shows the % battery level.

IOS TOUCHPAD CONTROL COMBINATION:

Click	Press the trackpad with one finger until you feel a click.
Click and hold	Press and hold the trackpad with one finger.
Drag and drop	Click and hold an item, then move your finger across the trackpad.
Waking up the iPad	Click on the trackpad, or you can press any key
Dock opening	With one finger, move the pointer below the bottom edge of the display.
Return to desktop	Swipe up with three fingers.
Slide Over mode display	With one finger, move the pointer beyond the right edge of the display. To hide Slide Over mode, swipe right again.
Opening of the Control Centre	Drag the pointer with one finger to select the status icons in the top right corner, then click. You can also select the status icons in the top right corner and then swipe up with one finger.
Opening of the Notification Centre	Move the pointer with one finger to select the status icons in the top left corner, then click.
Scrolling up and down	Swipe up or down with two fingers.
Scroll left and right	Swipe left or right with two fingers.
Zoom in/out	Place two fingers close together. Open your fingers to zoom in, pinch to zoom out.
Open a search from the desktop	Swipe down with two fingers.
To open the application switcher	Swipe up with three fingers, pause for a moment, then lift your fingers. You can also clasp four fingers together, pause for a moment and then lift them.
Switch between open apps	Swipe left or right with three fingers.
Opening today's view	On the desktop or lock screen, swipe right with two fingers.
Secondary clicks	A two-finger click brings up a quick action menu for various items, such as desktop icons, messages in your inbox or the Camera button in Control Centre.

TECHNICAL SPECIFICATIONS:
- Bluetooth: 5.2
- Operating distance: 10 m
- Chipset: PAR2860QN
- Working wireless frequency: 2.40 - 2.48 GHz
- Operating voltage: 3.0 - 4.2 V
- Operating current: < 50 mA
- Standby current: < 5 mA
- Sleep current: 5.5 mA < 90 uA
- Charging current: 420 mA
- Standby time: > 100 days
- Charging time: 1-2 hours
- Battery capacity: 500 mAh
- Continuous operation: 100 hours
- Key switch strength: 60 ±15 g
- Keyswitch lifetime: ≤5 million keystrokes
- Dimensions: 252 x 195 x 16 mm
- Weight: 631 g

NOTES:
In case of a problem, turn the keyboard off and on again.
The product is warranted according to the laws of the countries where it is sold. In case of service problems, contact the dealer from whom you purchased the device.
FIXED assumes no responsibility for damages caused by improper use of the product.

PRODUCT CARE AND MAINTENANCE
If the device is not used for an extended period of time, it is necessary to charge the battery every two to three months to prevent damage and to avoid reducing the performance of the device. Use a soft cloth to clean the goods.

SECURITY MEASURES
Do not expose the device to rain or snow or immerse it in water.
Do not leave the device in the car in the sun.
Do not expose the device directly to sunlight or leave it near heat sources.
Do not use the device if it has been subjected to a severe impact, if it has been dropped, or if it is damaged in any way.
Do not disassemble the equipment, there is a risk of electric shock and/or burns. Do not modify the power cord.
Keep the goods out of the reach of children. Unauthorized opening or modification of any part of the product will void the warranty.
- Storage temperature: 0°C to 35°C.
- Operating temperature: 0°C to 40°C

TROUBLESHOOTING:
If you have any problems with your product, you can contact our support at www.fixed.zone/podpora

(Applicable in countries with separate collection systems for recyclable materials).
Old products must not be disposed of with household waste! If the product no longer works, dispose of it in accordance with the applicable regulations in your country. This ensures that old products are recycled in a professional manner and also eliminates negative consequences for the environment. For this reason, the electrical equipment is marked with the symbol shown here.

This product is CE marked in accordance with EMC Directive 2014/30/EU and RoHS Directive 2011/65/EU. FIXED.zone a.s. hereby declares that this product complies with the essential requirements and other relevant provisions of the EMC 2014/30/EU and 2011/65/EU.

FIXED.zone a.s.
Kubatova 6
České Budějovice 37004
Czech Republic